



SCOREBOARD INSTRUCTIONS for Kin Centres & Elksentre

To Set Game Info:

- Turn the clock off and on again
- Press "Menu"
- Press "Clear"
- Enter code (062) for game info
- Press "Set Main Clock"
- Key in length of period with an additional zero (eg 25000 for 25 minutes)
- Press "Enter"
- Press "Period"
- Key in "1" on keypad for 1st period
- Press "Enter"
- Press "Start" when puck drops to begin game
- Same process to start each period just changing the period number as required

To set the time of Day

- Turn the clock off and on again
- Press "Menu"
- Press "Clear"
- Enter code (099) for time of day
- Press "Enter" (press it 2 times)
- Press "Set Main Clock"
- Key in the digits of the actual time
- Press "Enter"

To Enter A Goal

- Use Home or Guest areas on panel
- Press <score +1> on appropriate side
- To correct an error – press score on appropriate side, enter correct #, press "Enter"

To Put Up a Penalty

- Press "Player Penalty" (on appropriate side)
- Press "Enter" 3 times – 2:00 min penalty automatically come up on clock
- Penalty clock with automatically start with clock if stop time

Running Time Games

- Or Key in "300" for a 3 minute penalty etc...
- Press "Enter" when puck drops for running time

To Clear A Penalty:

- Press "Player Penalty"
- Press "Up" or "Down" arrow to choose which penalty to clear (if more than one)
- Press "Clear"
- Press "Enter"

FOR STOP TIME GAMES: simply hit stop and start at the effective stop (whistle) and start (puck drop) of each play

FOR RUN TIME GAMES: simply hit start at the beginning of the period and let the time run down. Penalties are entered as the clock is running. Press enter to start a penalty when puck drops.